

# Just Refill

## Refill Instructions - Brother LC01

**Brother:** HC-2500, HS-5000, HS-5300,  
MFC-700, MFC-700c, MFC-3000, MFC-7000, MFC-7000c,  
MFC-7200c, MFC-7200fc.

### Black and Colour Cartridges

1. Make a 3mm filling hole in the top of the cartridge using the drill bit supplied with the kit. (See **fig.1**)
2. Assemble the syringe and steel filling tube and fill with appropriate colour ink.
3. SLOWLY inject ink into the filling hole.  
**IMPORTANT:** Cartridge contains a sponge and a slight resistance may be felt.
4. When ink overflows from filling hole, cartridge is full. Stop injecting ink immediately.
5. Seal the hole with the plug provided. If the plug seal is not airtight, then secure and seal plug with strong adhesive tape. This seal **MUST** be airtight, if not cartridge will leak.
6. Unused ink may be returned to bottle.  
**IMPORTANT:** Clean syringe with water and dry for future use or use with different colour ink.
7. Leave cartridge to stand on a protective, non-absorbent surface overnight to ensure no leakage and to give the ink time to fully saturate the sponge.

**IMPORTANT:** For best results, refill whilst ink still remains in cartridge. Empty cartridges should be refilled immediately.

